

Fitting Guide – Mudguard Set - Part No. 101234

Note! Not suitable for rim brake equipped bikes.

Tools required: Metric Allen keys, 8mm and 19mm spanner. We suggest using Loctite or a similar product to secure threads.

Fitting the guards can be quite fiddly, it is easier with a work stand to support the bike and a second pair of hands. Also, take a look at the images online at dysonbikes.com.au/mud for reference.

Feel free to call us first before attempting on 03 9532 3132 for guidance.

Steps

1. Mount support arms to guards - straight arms for the longer rear guard and L shaped to smaller front guard, ref image below.
2. Remove rear wheel taking note of the position of axle washers. It is a good idea to take some photos for reference when reassembling.
3. Fit rear guard to frame. Some models use the small black spacer on the lower mounting point, marked 'B'. Depending on when the bike was built the spacer may be on the frame already and the additional one is not required.
4. Fit screw to point 'C'.
5. Mount arms to rear of frame at point 'A'.
6. Refit rear wheel.
7. Fit front guard to top rear of front fork using the screw with the oversize head, point 'D'.
8. Fit arms to fork.
9. Check for alignment and adjust as required, check tensions of all fasteners.

