



BLINDER LINK RACK



QUICK START GUIDE



WHAT'S IN THE BOX



OPERATION



POWER BUTTON

LONG PRESS - ON/OFF
STANDARD PRESS - CYCLES THROUGH ALL 8 MODES

MOUNTING



REMOVE THE LIGHT FROM THE MOUNT




INSERT BOLTS & WASHERS



TIGHTEN THE BOLTS



- DIFFERENT PANNIER RACK PLATES CAN VARY IN THICKNESS
- IF THE MOUNT IS LOOSE AFTER TIGHTENING THE BOLTS, USE THE EXTRA WASHERS PROVIDED TO ADD THICKNESS




RETURN THE LIGHT TO THE MOUNT


MOUNTING WITH ADAPTOR



WEARABLE



THE INTEGRATED CLIP-MOUNT TURNS THE BLINDER LINK INTO A WEARABLE LIGHT



- THE CLIP-MOUNT IS DESIGNED TO MOUNT TO THICK MATERIALS AND STRAPS
- MAKE SURE THE LIGHT IS MOUNTED VERTICALLY WITH THE POWER BUTTON AT THE TOP
- BEFORE WEARING THE LIGHT, MAKE SURE THE LIGHT IS TIGHTLY FITTED AND SECURE BEFORE USE

BATTERY STATUS




WHEN THE BATTERY IS RUNNING LOW, THE RED LED WILL APPEAR

CHARGING



CAREFULLY OPEN CHARGING-PORT HATCH



INSERT USB C CHARGING CABLE
RED LED INDICATES CHARGING

GREEN LED INDICATES FULLY CHARGED

MODES & RUNTIMES

MODE	LUMENS	RUNTIME
Steady High	35	4hr
Steady Low	20	7hr
High Flash	100	7hr
Low Flash	50	19hr
Fading Flash	30	14hr
Pulse Flash	70	19hr
Accelerating Flash	30	7hr
Eco Flash	30	100hr

DESIGNED BY KNOG
MELBOURNE, AUSTRALIA

2 YEAR WARRANTY

KNOG.COM