

# Bondi and Tilba Display Instructions

## 1. Turning on and off

To switch on the bike, ensure the master power switch located on the underside of the battery is switched on, then press the 'M' button. To switch off, press and hold the 'M' button. The display will automatically power off after an extended period of inactivity to conserve battery power.

## 2. Battery level

The current state of battery charge is shown on the display. When fully charged 6 bars will be shown. As you ride the number of bars will decrease. Note, it is normal for the number of bars to decrease under high loads such as climbing hills, then increase after.

## 3. Assist levels

You have the choice of five levels of pedal assistance with '1' being the lowest, to '5' being the highest. You can also ride without pedal assistance in level '0' or 'H', trip and ODO will still function in these modes. In level 'H' the pedal assist will not function, but the thumb throttle will. Power output is shown in the top left.

## 4. Thumb throttle

The thumb throttle can be used to activate the motor output to a maximum of 200 Watts without pedalling and can be used in all assist levels apart from '0'. For hill climbing it is not recommended to use the throttle alone, rather use pedal assist modes as your pedalling with add to the motor power.

## 5. Lighting

To active the front and rear lights, press and hold the '+' key for 2-seconds. Repeat this procedure and the lights will go to flash mode. Switch off by pressing and holding '+' for 2-seconds.

## 6. Walk function

The walk function is activated by pressing and holding the '-' key. The bike will be propelled along at approximately 6kph or less. This feature is intended to be used when pushing the bike up a steep hill for example, not when riding.

## 7. Speed

The approximate road speed in kilometres per hour is shown on the top right of the display.

## 8. Trip/ODO function

The display records trip information. You can cycle between these readings by briefly pressing 'M'. Reset the trip distance by pressing and holding both the '+' and '-' keys at the same time for approximately 4-seconds. Press both '+' and '-' keys together to return to main display. If the bike is ridden without the display on the distance travelled during this time will not be recorded.

If you need any further information, please feel free to contact us on 03 9532 3132 or by email [info@dysonbikes.com.au](mailto:info@dysonbikes.com.au).

