



image: jason fitz/ibcor/the roadivist

Thanks for choosing **aeroe**

We hope that this is the start of a long and happy relationship that will enable you to use your bike more often, for more adventures in an easier and more enjoyable way.

If you're like us and tend to skip the instructions and just start putting it together. . . . we understand. However if you would like some help getting set up, below are some important and handy tips and tricks for installing your aeroe gear.

All you need to install any of our products is a standard 5mm allen key. Take a moment to familiarise yourself with some of the jargon below shown on the **Quick Mount Pod**. The following steps will then allow you to get setup quickly and easily so you can get out and start enjoying your new gear!



aeroe **'pod'** which gets mounted to the **'uni mount'** located on top or sides of the **'spider rear rack'**.



Tool required for install - **5mm allen key**



pod **'zip'** and **'straps'** for quick + easy access to gear

**'uni mount'** attachment. (at rear of pod not shown). The universal mount allows the **'pod'** to attach to **'spider rear rack'** as shown in first step below

**'quick release tab'** pull to release pod in seconds

We love seeing and hearing about your adventures around the world. . . . if you want to reach out or still need installation help - we would love to hear from you! You can reach us at [team@aeroe.com](mailto:team@aeroe.com) or on facebook and instagram [#aeroebikepack](https://www.instagram.com/aeroebikepack) or check out [aeroe.com](http://aeroe.com) for more information.

Thanks again from the aeroe team!

start here


1



You should already have your **spider rear rack** installed on your bike. If not refer to our **spider rear rack** instructions and install this on your bike as shown above. The next step is to simply install the **uni mount** which comes with your **pod** onto the **spider rear rack** so that it looks like the image above. The **uni mount** can be installed on the sides or top of the **spider rear rack**.

The **uni mount** is installed with a **5mm allen key** as shown in the next image.

2



Install the **uni mount** onto the **spider rear rack** by locating the male and female parts of the **uni mount** onto the side or top of the **spider rear rack** tube. We suggest tightening at first to about 75% tight, to form some stability, and make final adjustments to final position before tightening fully to a 'hand tight' strength.

3



Pull strap release

Once the **uni mount** is in place, get familiar with the **pod** and how it attaches to the **uni mount**. Simply pull the **quick release tab** on the **pod**. You will note this will pull in and out the small lug which locks (and releases) the **pod** in place once attached to the **uni mount** and allows the pod to be rotated 360 degrees. The 3 indents in the **pod** should line up with the 3 protrusions on the **uni mount** when attaching.


4



Next, lets line up the **pod** and **uni mount** which should now be installed on the **spider rear rack**. Once the **pod** is aligned, simply push the **pod** into the **uni mount** and then rotate the **pod**, until you hear a 'click'. This means the **pod** is now locked into place.

**HOT TIPS** the easiest way to line up the **pod** with the **uni mount** is to align one of the three indents in the **pod** with one of the three protrusions in the **uni mount**. Once you do this a few times it becomes very easy.


5



360 degrees of rotation

To position the **pod** to the preferred location simply pull the **quick release tab** and at the same time, rotate the **pod** until you hear another 'click'. There are a number of possible 360 degrees positions for the pod to be rotated around to give you maximum flexibility of position, depending on heel clearance, dropper post, weight distribution or zero dynamic preferences. Recommended max load per pod is 7kgs (15 pounds).

6



Your setup should now look something like this and be ready to use! To release the **pod**, simply pull the **quick release tab** again and rotate slightly and pull the pod towards you and the **pod** should come out of place for easy access or to take your gear with you. Access your gear via the pods **zip** and secure your gear inside your bag using the pods **straps**. Enjoy!

**HOT TIPS** you can setup the **spider rear rack** with **pods** either side or on top depending on preferences, or people often use a **pod** either side and our spider rear rack **cradle** on top if they have a tent or dry bag they like to take with them.